

WHOLE GRAIN Muffin

WET ingredients

2 TBS. MOLASSES
1 CUP BUTTERMILK
2 EGGS



DRY ingredients

1 CUP ROLLED OATS (ground)
1 CUP WHOLE WHEAT FLOUR
2 1/2 TSP. BAKING POWDER
1/2 TSP. BAKING SODA
1/2 TSP. SALT
3 TBS. BROWN SUGAR

IN A LARGE BOWL, COMBINE ALL WET INGREDIENTS AND MIX THOROUGHLY. IN A SEPARATE BOWL, COMBINE THE DRY INGREDIENTS AND MIX TOGETHER. CAREFULLY POUR THE WET INGREDIENTS OVER THE DRY INGREDIENTS AND STIR UNTIL BATTER IS FORMED. POUR BATTER INTO MUFFIN PAN AND BAKE AT 350° FOR 20 MINUTES.